

# Capacitive TouchScreen

System	kernel version	Touch mode	Note
Ubuntu10.10	2.6.35	Single Touch	
Ubuntu11.04	2.6.38	Single Touch	
Ubuntu12.04LTS	3.2	Multi-Touch	
Ubuntu12.10	3.5	Multi-Touch	
Ubuntu14.04LTS	3.13	Multi-Touch	
Ubuntu16.04LTS	4.4	Multi-Touch	
Ubuntu17.04	4.09	Multi-Touch	
Ubuntu18.04LTS	4.15	Multi-Touch	
Ubuntu18.10	4.18	Multi-Touch	Should work for release 18.10 and above
CentOS7.3-1611	3.10.0-514	Multi-Touch	
CentOS7.5-1804	3.10.0-862	Multi-Touch	Should work for release 7.5-1804 and above
Fedora15	2.6.38	Single Touch	
Fedora16	3.1	Multi-Touch	
Fedora18	3.6	Multi-Touch	Should work for release 18 and above
Debian7	3.2	Multi-Touch	
Debian9	4.9	Multi-Touch	Should work for release 9 and above
openSUSE11.4	2.6.37	Single Touch	
openSUSE12.1	3.1.0	Multi-Touch	Should work for release 12.1 and above

# Infrared TouchScreen

System	kernel version	2-point touchscreen	Single touchscreen	Note
Ubuntu10.10	2.6.35	Not Surpport Touch	Single Touch	
Ubuntu12.04	3.2	Multi-Touch	Single Touch	
ubuntu12.4LTS	3.1	Multi-Touch	Single Touch	
Ubuntu12.10	3.5	Multi-Touch	Single Touch	
Ubuntu14.04LTS	4.4	Multi-Touch	Single Touch	
Ubuntu16.04LTS	4.15	Multi-Touch	Single Touch	
Ubuntu17.04	4.09	Multi-Touch	Single Touch	
Ubuntu18.04LTS	4.15	Multi-Touch	Single Touch	
Ubuntu18.10	4.18	Multi-Touch	Single Touch	Should work for release 18.10 and above with single touch and 2 points touch.
CentOS7.3-1611	3.10.0-514	Multi-Touch	Not Surpport Touch	
CentOS7.5-1804	3.10.0-862	Multi-Touch	Not Surpport Touch	Should work for release 7.5-1804 and above with 2 points touch.
Fedora18	3.6.10	Multi-Touch	Single Touch	Should work for release 18 and above with single touch and 2 points touch.
Debian7	3.2	Multi-Touch	Single Touch	
Debian9	4.9	Multi-Touch	Single Touch	Should work for release 9 and above with single touch and 2 points touch.
openSUSE11.4	2.6.37	Not Surpport Touch	Single Touch	
openSUSE12.1	3.1.0	Multi-Touch	Not Surpport Touch	
openSUSE12.3	3.7.10	Multi-Touch	Single Touch	
openSUSE15.0	4.12	Multi-Touch	Single Touch	Should work for release 15.0 and above with single touch and 2 points touch.

# SAW TouchScreen

System	Kernel version	ST21.5-M4 (21.5 4-Points)	STD21.5-M10(21.5 10-Points)	Single touchscreen	Note
Ubuntu10.10	2.6.35	Not Surpport Touch	Not Surpport Touch	Single Touch	
Ubuntu11.04	2.6.38	Single Touch	Not Surpport Touch	Not Surpport Touch	
Ubuntu11.10	3.0	Single Touch	Not Surpport Touch	Not Surpport Touch	
Ubuntu12.04	3.2	Not Surpport Touch	Not Surpport Touch	Single Touch	
ubuntu12.4LTS	3.1	Multi-Touch	Multi-Touch	Single Touch	
Ubuntu12.10	3.5	Multi-Touch	Multi-Touch	Single Touch	
Ubuntu14.04LTS	4.4	Multi-Touch	Multi-Touch	Single Touch	
Ubuntu16.04LTS	4.15	Multi-Touch	Multi-Touch	Single Touch	
Ubuntu17.04	4.09	Multi-Touch	Multi-Touch	Single Touch	
Ubuntu18.04LTS	4.15	Multi-Touch	Multi-Touch	Single Touch	
Ubuntu18.10	4.18	Multi-Touch	Multi-Touch	Single Touch	Should work for release 18.10 and above with single touch and multi-touch.
CentOS7.3-1611	3.10.0-514	Multi-Touch	Multi-Touch	Not Surpport Touch	
CentOS7.5-1804	3.10.0-862	Multi-Touch	Multi-Touch	Not Surpport Touch	Should work for release 7.5-1804 and above with multi-touch.
Fedora18	3.6.10	Multi-Touch	Multi-Touch	Single Touch	Should work for release 18 and above with single touch and multi-touch.
Debian7	3.2	Not Surpport Touch	Multi-Touch	Single Touch	
Debian9	4.9	Multi-Touch	Multi-Touch	Single Touch	Should work for release 9 and above with single touch and multi-touch.
openSUSE11.4	2.6.37	Multi-Touch	Multi-Touch	Single Touch	
openSUSE12.1	3.1.0	Multi-Touch	Multi-Touch	Single Touch	
openSUSE12.3	3.7.10	Multi-Touch	Multi-Touch	Single Touch	
openSUSE15.0	4.12	Multi-Touch	Multi-Touch	Single Touch	Should work for release 15.0 and above with single touch and multi-touch.